



Installation Basics

Adhesive should be fully bonded to the glass within 36 hours after factory application. If any of the image adhesive residue remains on the face of the glass for whatever reason, a citrus-based adhesive remover is recommended.

Any seaming should be filled in using a clear silicone adhesive.

Installation is really no different than installing a piece of mirror or even the “real” thing in most instances. Please consult a reputable glazing professional for all your installation needs. The main difference is that fabrication in the field is more difficult--much like working with a piece of laminated glass--due to the photographic adhesive film. Please measure the project carefully so that fabrication can be executed right the first time. Take into account the standard industry tolerances of +/- 1/16 of an inch.

For a list of approved adhesives, please visit our Approved Adhesives tab on the technical page.